

ELEVATE EVERYTHING

# MONOGRAM

Models listed below are partial model numbers only. For the perfect match use the beginning sequence of your model number.

APPROVED FOR INSTALLATION ABOVE MONOGRAM WALL OVENS			WALL OVENS					ADVANTIUM		
			30" Single Wall Oven					27" Single Wall Oven	120 Volt	
			ZET9050	ZET1F	ZET1P	ZET1S	ZET1D	ZEK7000	ZSC1201	ZSC1202
COOKTOPS	30" Electric Cooktop	ZEU30R*J	●		●	●		●	●	
	36" Electric Cooktop	ZEU36R*J	●		●	●		●	●	
	30" Gas Cooktop	ZGU30R	●		●	●		●	●	
		ZGU384N	●		●	●	●			
	36" Gas Cooktop	ZGU36E	●		●	●		●	●	
		ZGU36R	●		●	●		●	●	
		ZGU385N	●		●	●				
30" Induction Cooktop	ZHU30R*J	●		●	●	●	●	●		
36" Induction Cooktop	ZHU36R*J	●		●	●	●	●	●		

\*Indicates cooktop as may be installed centered over one wall oven (see cooktop over wall oven matrix)

✕ 14" between cutouts ■ 30" between cutouts

APPROVED FOR INSTALLATION NEXT TO MONOGRAM WALL OVENS			WALL OVENS					ADVANTIUM		
			30" Single Wall Oven					27" Single Wall Oven	120 Volt	
			ZET9050*	ZET1F	ZET1P*	ZET1S*	ZET1D	ZEK7000*	ZSC1201	ZSC1202
WALL OVENS	30" Single Wall Oven	ZET9050*	●	✕	●	●	●			
		ZET1F	✕	■	✕	✕	✕			
		ZET1P*	●	✕	●	●	●			
		ZET1S*	●	✕	●	●	●			
		ZET1D*	●	✕	●	●	●			
	27" Single Wall Oven	ZEK7000*					●			
	Bi Advantium	ZSC1201						●	●	
ZSC1202							●	●		

ELEVATE EVERYTHING

# MONOGRAM

Models listed below are partial model numbers only. For the perfect match use the beginning sequence of your model number.

APPROVED FOR INSTALLATION ABOVE MONOGRAM WARMING DRAWERS			WARMING DRAWERS	
			27" Warming Drawers	30" Warming Drawers
			ZJ7000	ZW9000
COOKTOPS	30" Electric Cooktop	ZEU30R*J	●	●
	36" Electric Cooktop	ZEU36R*J		●
	30" Gas Cooktop	ZGU30R	●	●
		ZGU384N	●	●
	36" Gas Cooktop	ZGU36E/R		●
		ZGU385N		●
	30" Induction Cooktop	ZHU30R*J	●	●
	36" Induction Cooktop	ZHU36R*J		●
WALL OVENS	30" Single Wall Oven	ZET9050*		●
		ZET1F		●
		ZET1P		●
		ZET1S		●
		ZET1D		●
	30" Double Wall Oven	ZET9550		●
		ZET2S		●
		ZET2P		●
		ZET2F		●
	27" Single Wall Oven	ZEK7000*	●	
	27" Double Wall Oven	ZEK7500	●	